

Simple Table Instructions - BASIC



- 1) Start by attaching the 10-7 Tees to end of Pipe A
- 2) Now slide each Pipe B through the 10-7 Tees on Pipe A
- 3) Attach the remaining 10-7 Tees to the ends of Pipe B.
- 4) Slide Pipe C into the 10-7 Tees and leave about 3 inches sticking out. Tighten setscrews lightly.
- 5) Attach the 61-7 flanges on the long side of Pipe C
- 6) Place your desktop on the ground, with the bottom facing up.
- 7) Flip the pipe frame over so that the 61-7 flanges are now lying flat on the bottom of the desktop.

Footing Attachment Guide

Plugs

Hammer the 133-7 plastic plugs into the bottom of the pipe legs.

Flanges

Place a 61-7 fitting on each leg and tighten them into place.

Casters

Tighten nut on caster until the rubber stopper is as wide as the pipe opening.

Insert rubber stopper into pipe. It should be snug.

Using a wrench, tighten the bolt on the bottom of the caster. This will continue to expand the rubber stopper and ensure the caster will stay in place

Tools Needed:

Allen Wrench (Included)
Screw Driver
Rubber Mallet (for plugs)
Crescent Wrench (for casters)
Level

Frame Parts

6 x 10-7 Tees
4 x 61-7 Flanges
1 x (A) Width Pipe
2 x (B) Depth Pipes
4 x (C) Leg Pipes

Footing Parts (one of below)

4 x 133-7 Plastic Plugs
or
4 x 61-7 Flanges
or
4 x Casters (2 Braking / 2 Non-Braking)

Tips:

Don't over-tighten the setscrews.

Tightening a fitting will mark the pipe, so be careful where you do it.

Call us if you get stuck!

1-888-527-2278 - Customer Service

- 8) Move the legs of the frame on the desktop until the flanges are about 4 inches from each edge.

- 9) Attach the 61-7 flanges to the desktop with the appropriate fastener (fasteners not provided).

- 10) Attach the appropriate footing (see below)

- 11) Turn the desk right side up! You are done! You can adjust the individual fittings to make sure that everything is level and square.